

Instructions for the Assembly of Floor Hardware

1. On the ground, connect track, using splices and curves (if applicable), in the desired formation.
2. Starting from one end, begin raising track structure by placing upright columns under each splice or curve, inserting the peg from the splice or curve into the upright column.
3. Once entire track structure is standing, lift each upright column just enough to slide a base plate into place under the column so that the column slides onto the peg of the base plate.
4. Fasten end stop onto one end of track, put all the roller hooks into the other end and fasten the other end stop to the track.
5. Hang curtains from roller hooks.